



# HORSESHOE GUIDE | GUIDA HORSESHOE


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>ABARTH (I)</b> 				
500	2008	Today	FT22U	TK60/TK100
Grande Punto	2007	2010	FT22U	TK60/TK100
Punto Evo	2010	Today	FT22U	TK60/TK100

MAKE (USA)	FROM	TO	HORSESHOE	HEAD
<b>ACURA (USA)</b> 				
CL	1998	2003	HD90U	TK100
CSX (Canada)	2006	2011	HD1U	TK60/TK100
Integra	2000	2001	HD90U	TK100
MD-X	2001	2006	HD90U	TK100
MD-X	2007	Today	HD1U	TK60/TK100
NSX	1997	2005	HD90U	TK100
RDX	2007	Today	HD1U	TK60/TK100
RL	1996	2004	HD90U	TK100
RL	2005	2010	HD90U	TK60/TK100
RSX	2002	2006	HD90U	TK100
TL	1999	2003	HD90U	TK100
TL	2004	2006	HD90U	TK60/TK100
TL	2007	Today	HD1U	TK60/TK100
TSX	2004	2008	HD90U	TK60/TK100
TSX	2009	Today	HD1U	TK60/TK100
ZDX	2010	Today	HD1U	TK60/TK100

MAKE (I)	FROM	TO	HORSESHOE	HEAD
<b>ALFA ROMEO (I)</b> 				
147	1998	Today	FT22U	TKM
156	2001	2003	FT22U	TK60/TK100
156	2003	2005	FT22U	TKM
156 (Australia)	2007	Today	AR20U	TK60/TK100
156 Sport Wagon	2001	2007	FT22U	TK60/TK100
164	1995	1998	AR16U	TK100
166	2002	2004	AR20U	TK60/TK100
166	2004	2008	FT22U	TK60/TK100
Giulietta	2010	Today	FT22U	TK60/TK100
GT	2004	Today	FT22U	TKM
MiTo	2008	Today	FT22U	TK60/TK100
Spider	2006	Today	FT22U	TK60/TK100


MAKE (I)	FROM	TO	HORSESHOE	HEAD
<b>APRILIA (I)</b> 				
Dorsoduro 1200	2011	Today	ZAD20U	TK100
Mana 850	2008	Today	ZAD20U	TK100
RSV 1000	2004	Today	ZAD30U	TK100
Shiver 750	2010	Today	ZAD20U	TK100
Tuono 1000R	2004	Today	ZAD30U	TK100

MAKE (D)	FROM	TO	HORSESHOE	HEAD
<b>AUDI (D)</b> 				
80/90	1995	1997	V35U	TK100
A1	2010	Today	V66U	TKM
A2	2000	2005	V66U	TKM
A3	1996	1997	V66U	TK100
A3	1997	Today	V66U	TKM
A4	1995	1996	V35U	TK100
A4	1996	1997	V66U	TK100
A4	1997	Today	V66U	TKM
A4 Cabrio	1995	1996	V35U	TK100
A4 Cabrio	1996	1997	V66U	TK100
A4 Cabrio	1997	Today	V66U	TKM
A6	1995	1996	V35U	TK100
A6	1996	1997	V66U	TK100
A6	1997	Today	V66U	TKM
A8	1995	1996	V35U	TK100
A8	1996	1997	V66U	TK100
A8	1997	Today	V66U	TKM
Allroad	2000	Today	V66U	TKM
Coupè	1995	1996	V35U	TK100
Coupè	1996	1997	V66U	TK100
Coupè	1997	Today	V66U	TKM
Q7	2006	Today	V66U	TKM
S2	1995	1996	V35U	TK100
S2	1996	1997	V66U	TK100
S2	1997	Today	V66U	TKM
S3	2001	Today	V66U	TKM
S4	2002	Today	V66U	TKM
S6	1995	1996	V35U	TK100
S6	1996	1997	V66U	TK100
S6	1997	Today	V66U	TKM
S8	1998	Today	V66U	TKM
S8	2006	Today	V66U	TK60/TK100
TT	1998	Today	V66U	TKM

MAKE (D)	FROM	TO	HORSESHOE	HEAD
<b>BMW (D)</b> 				
Some models	2007	Today	BM2U	TK60/TK100
X 3	2007	Today	BM2U	TK60/TK100
Z 4	2006	Today	BM2U	TK60/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>BUICK (USA)</b> 				
Allure	2010	Today	VX5U	TK60/TK100
Enclave	2008	Today	B106U	TK60/TK100
LaCrosse	2010	Today	VX5U	TK60/TK100
Lucerne	2006	Today	B106U	TK60/TK100
Regal	2000	2005	Y160U	TKM
Verano	2012	Today	VX5U	TK60/TK100


MAKE (USA)	FROM	TO	HORSESHOE	HEAD
<b>CADILLAC (USA)</b> 				
Catera	1997	1999	VX1U	TK100
CTS	2003	2005	Y160U	TKM
CTS	2008	Today	B106U	TK60/TK100
CTS-V	2004	2005	Y160U	TKM
DTS	2006	Today	B106U	TK60/TK100
Escalade	2007	Today	B106U	TK60/TK100
Escalade EXT	2007	Today	B106U	TK60/TK100
SRX	2004	2006	B106U	TKM
SRX	2007	2009	B106U	TK60/TK100
SRX	2010	Today	VX5U	TK60/TK100
STS	2005	Today	B106U	TK60/TK100
XLR	2004	2009	B106U	TK60/TK100


MAKE (EUR)	FROM	TO	HORSESHOE	HEAD
<b>CHEVROLET (EUR)</b> 				
Aveo	2006	2011	DAE48SU	TKM
Aveo	2011	Today	VX5U	TK60/TK100
Captiva	2006	Today	DAE47U	TK60/TK100
Cruze	2008	Today	VX5U	TK60/TK100
Kalos	2002	2006	DAE48SU	TKM
Lacetti	2002	2004	DAE48SU	TKM
Lacetti	2004	Today	DAE48SU	TK40/TK100
Lanos	2002	2004	DAE47SU	TK100
Leganza	2000	2008	DAE47SU	TK100
Matiz	2001	2005	DAE49U	TK100
Matiz	2005	Today	DAE49U	TKM
Matiz	2006	Today	DAE48U	TK100
Nubira	2000	2002	DAE48SU	TKM
Nubira	2002	2006	DAE48U	TK100
Nubira	2005	Today	DAE49U	TKM
Nubira SW	2004	Today	DAE48SU	TK40/TK100
Orlando	2010	Today	VX5U	TK60/TK100
Spark	2010	Today	DAE49U	TKM
Tacuma	2000	2008	DAE48SU	TKM

MAKE (USA)	FROM	TO	HORSESHOE	HEAD
<b>CHEVROLET (USA)</b> 				
Agile	2009	Today	VX5U	TK60/TK100
Avalanche	2007	2008	DAE48SU	TKM
Avalanche	2007	Today	B106U	TK60/TK100
Aveo	2004	2010	DAE48SU	TK100
Aveo	2006	2011	DAE48SU	TK100
Camaro	2010	Today	VX5U	TK60/TK100
Cobalt	2006	Today	B106U	TK60/TK100
Colorado	2008	2011	DAE48SU	TKM
Cruze	2011	Today	VX5U	TK60/TK100
Epica	2004	2007	DAE47U	TK100
Equinox	2007	2009	B106U	TK60/TK100
Equinox	2010	Today	VX5U	TK60/TK100
Express	2008	Today	B106U	TK60/TK100
HHR	2006	Today	B106U	TK60/TK100
Impala	2006	Today	B106U	TK60/TK100
Malibu	2004	Today	B106U	TK60/TK100
Montecarlo	2006	2007	B106U	TK60/TK100
Silverado	2014	2015	VX6U	TK60/TK100
Silverado (HD)	2007	Today	B106U	TK60/TK100
Sonic	2012	Today	VX5U	TK60/TK100
Suburban	2007	Today	B106U	TK60/TK100
Tacuma	2000	2008	DAE48SU	TKM
Tahoe	2007	Today	B106U	TK60/TK100
Trailblazer	2006	Today	B106U	TK60/TK100
Traverse	2009	Today	B106U	TK60/TK100

MAKE (USA)	FROM	TO	HORSESHOE	HEAD
<b>CHRYSLER (USA)</b> 				
200	2011	Today	Y160U	TK60/TK100
300, 300C	2005	2007	Y160U	TK60/TK100
300, 300C	2008	Today	Y170U	TK60/TK100
300M	1999	2004	Y160U	TK40/TK100
Aspen	2007	2009	Y160U	TK60/TK100
Cirrus	1999	2000	Y160U	TK40/TK100
Cirrus Convertible/Sedan	2001	Today	Y160U	TK40/TK100
Concorde	1998	2004	Y160U	TK40/TK100
Country	2001	2005	Y160U	TK40/TK100
LHS	1999	2001	Y160U	TK40/TK100
Neon	1998	2000	Y160U	TK40/TK100
Neon	2000	2005	Y160U	TK40/TK100


# HORSESHOE GUIDE | GUIDA HORSESHOE


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>CHRYSLER (USA)</b> 				
New Yorker	1998	2004	Y160U	TK40/TK100
Pacifica	2004	2008	Y160U	TK60/TK100
PT Cruiser	2001	2005	Y160U	TK40/TK100
PT Cruiser	2006	Today	Y160U	TK60/TK100
PT Cruiser LE	2001	2005	Y160U	TK40/TK100
Sebring	2007	2011	Y160U	TK60/TK100
Sebring Convertible	1998	2006	Y160U	TK40/TK100
Sebring Convertible	2007	2011	Y160U	TK60/TK100
Sebring Coupe	2001	2002	MT11U	TK40/TK100
Sebring Sedan	1999	2006	Y160U	TK40/TK100
Sebring Sedan	2007	Today	Y160U	TK60/TK100
Stratus	1998	2006	Y160U	TK40/TK100
Town & Country	2001	2004	Y160U	TK40/TK100
Town & Country	2004	2007	Y160U	TK60/TK100
Town & Country	2007	Today	Y170U	TK60/TK100
Vision	1998	Today	Y160U	TK40/TK100
Voyager	2001	2003	Y160U	TK40/TK100
Voyager	2004	2007	Y160U	TK60/TK100
Voyager	2004	Today	Y160U	TK60/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>CITROËN (F)</b> 				
Berlingo	1998	2001	CN22U	TK100
Berlingo	2001	2002	CN22U	TK60/TK100
C1	2005	Today	PG33U	TK40/TK100
C2	2003	Today	PG33U	TK60/TK100
C3	2002	Today	PG33U	TK60/TK100
C3-Picasso	2008	Today	PG33U	TK60/TK100
C4	2005	2009	PG33U	TK60/TK100
C4	2010	Today	PG33U	TK60/TK100
C4-Picasso	2006	Today	PG83U	TK60/TK100
C5	2001	2008	CN22U	TK60/TK100
C5	2008	Today	PG83U	TK60/TK100
C6	2006	Today	PG33U	TK60/TK100
C8	2002	Today	PG83U	TK60/TK100
C-Crosser	2007	Today	MT8SU	TK60/TK100
C-Zero	2011	Today	MT8SU	TK60/TK100
Dispatch	2002	2006	CN22U	TK60/TK100
Dispatch	2007	Today	PG83U	TK60/TK100
DS3	2010	Today	PG33U	TK60/TK100
DS4	2011	Today	PG33U	TK60/TK100
Evasion	1998	2002	CN22U	TK100
Jumper	1996	2001	FT50U	TK100
Jumper	2001	2005	CN22U	TKM
Jumper	2006	Today	FT22U	TK60/TK100
Jumpy	1998	Today	RN30U	TK100
Jumpy	2002	2006	CN22U	TK60/TK100
Jumpy	2007	Today	PG83U	TK60/TK100
Nemo	2008	Today	FT22U	TK60/TK100
Relay	1996	2001	FT50U	TK100
Relay	2001	2005	CN22U	TKM
Relay	2006	Today	FT22U	TK60/TK100
Saxo	1998	2000	CN22U	TK100
Saxo	2000	2003	CN22U	TK60/TK100
Xantia	1998	1999	CN22U	TK100
Xantia	2000	2001	CN22U	TKM
Xsara	1997	2000	CN22U	TK100
Xsara	2001	2006	CN22U	TK60/TK100
Xsara Picasso	2002	2007	CN22U	TK60/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>DACIA (RO)</b> 				
Duster	2010	Today	VE20U	TK60/TK100
Logan	2006	Today	VE20U	TK60/TK100
Sandero	2008	Today	VE20U	TK60/TK100
Symbol	2010	Today	RN30U	TK60/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>DAEWOO (ROK)</b> 				
Aveo	2006	2011	DAE48SU	TK100
Kalos	2002	2006	DAE48SU	TKM
Lacetti	2002	2004	DAE48SU	TK100
Lanos	2002	2004	DAE47SU	TKM
Leganza	1997	2000	DAE47U	TK100
Leganza	2000	2008	DAE47SU	TKM
Matiz	2001	2005	DAE49U	TKM
Matiz	2006	Today	DAE48U	TKM
Nubira	1997	2000	DAE48SU	TK100
Nubira	2000	2002	DAE48SU	TKM
Nubira	2002	2006	DAE48U	TK100
Nubira	2002	2008	DAE48U	TKM
Tacuma	2000	2008	DAE48SU	TKM

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>DAF (D)</b> 				
CF	2002	Today	RN30U	TKM
LF	2002	Today	RN30U	TKM
XF	2002	Today	RN30U	TKM

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>DAIHATSU (J)</b> 				
Charade	1997	2004	DAI1SU	TK24/TK100
Charade	2011	Today	TR56U	TK40/TK100
Copen	2002	Today	DAI1SU	TK40/TK100
Cuore	1998	2006	DAI1SU	TK24/TK100
Cuore	2007	Today	DAI1SU	TK40/TK100
Feroza	1995	1998	DAI1SU	TK24/TK100
Materia	2006	Today	DAI1SU	TK40/TK100
Move	1997	2002	DAI1SU	TK24/TK100
New Feroza	1995	Today	DAI1SU	TK24/TK100
Sirion	1998	2004	DAI1SU	TK24/TK100
Sirion	2005	Today	DAI1SU	TK40/TK100
Terios	1997	2005	DAI1SU	TK24/TK100
Terios	2006	Today	DAI1SU	TK40/TK100
Trevis	2007	Today	DAI1SU	TK40/TK100
YRV	2000	Today	DAI1SU	TK24/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>DODGE (USA)</b> 				
Avenger	2008	Today	Y160U	TK60/TK100
Caliber	2007	Today	Y160U	TK60/TK100
Caravan	2001	2003	Y160U	TK40/TK100
Caravan	2004	2007	Y160U	TK60/TK100
Challenger	2007	Today	Y170U	TK60/TK100
Challenger SRT8	2008	Today	Y170U	TK60/TK100
Charger	2006	Today	Y160U	TK60/TK100
Charger	2008	2011	Y170U	TK60/TK100
Dakota	2001	2004	Y160U	TK40/TK100
Dakota	2004	2011	Y160U	TK60/TK100
Durango	2001	2003	Y160U	TK40/TK100
Durango	2004	2010	Y160U	TK60/TK100
Durango	2011	Today	Y170U	TK60/TK100
Intrepid	1999	2004	Y160U	TK40/TK100
Intrepid Sedan, ES	2001	2004	Y160U	TK40/TK100
Journey	2009	Today	Y170U	TK60/TK100
Magnum	2005	2007	Y160U	TK60/TK100
Magnum	2008	2010	Y170U	TK60/TK100
Neon	2000	2005	Y160U	TK40/TK100
Nitro	2007	Today	Y160U	TK60/TK100
Ram	2002	2005	Y160U	TK40/TK100
Ram 1500	2009	Today	Y170U	TK60/TK100
Ram 1500/2500/3500	2006	2008	Y160U	TK60/TK100
Ram 2500/3500	2009	Today	Y160U	TK60/TK100
Sprinter	2007	2010	MB57U	TK100
Stratus Coupe	2001	2002	MT11U	TK40/TK100
Stratus Sedan	1998	2006	Y160U	TK40/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>EAGLE (USA)</b> 				
Vision	1998	Today	Y160U	TK40/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>FERRARI (I)</b> 				
612 Scaglietti	2004	2011	FT22U	TKM
California	2008	2011	FT22U	TKM


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>FIAT (I)</b> 				
500	2007	Today	FT22U	TK60/TK100
Albea	2002	Today	FT22U	TKM
Bravo	2007	Today	FT22U	TK60/TK100
Cinquecento	1995	1996	FT50U	TK100
Croma	1995	1997	FT50U	TK100
Doblò	2000	2006	FT22U	TKM
Doblò	2006	Today	FT22U	TK60/TK100
Ducato	1996	2001	FT50U	TK100
Ducato	2002	Today	FT22U	TKM
Ducato	2006	Today	FT22U	TK60/TK100
Fiorino	1995	2002	FT50U	TK100
Fiorino	2007	Today	FT22U	TK60/TK100
Grande Punto	2005	2009	FT22U	TK60/TK100
Idea	2003	2009	FT22U	TKM
Idea	2009	Today	FT22U	TK60/TK100
Linea	2007	Today	FT22U	TKM
Mille	2005	Today	FT22U	TKM
Multipla	1998	Today	FT1505U	TKM
Palio	2002	Today	FT1505U	TKM
Panda	1995	2002	FT50U	TK100
Panda	2003	2011	FT22U	TK60/TK100
Panda	2012	Today	FT22U	TK60/TK100
Punto	2000	2005	FT1505U	TKM
Punto	2000	2005	FT22U	TKM
Punto	2005	2008	FT22U	TK60/TK100
Punto Evo	2009	Today	FT22U	TK60/TK100
Qubo	2008	Today	FT22U	TK60/TK100
Scudo	2007	Today	PG83U	TK60/TK100
Sedici	2006	Today	SU19U	TK60/TK100
Seicento	1995	1996	FT50U	TK100
Seicento	2000	Today	FT1505U	TKM


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>FIAT (I)</b> 				
Siena	2002	Today	FT1505U	TKM
Stilo	2001	2007	FT22U	TKM
Ulysse	1996	2001	CN22U	TK100
Ulysse	2003	Today	PG83U	TK60/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>FORD (AUS)</b> 				
BF Falcon	2005	Today	FD40U	TK40/TK100
Escape	2005	Today	FD21U	TK40/TK100
Explorer	2000	2006	FD21U	TK40/TK100
Explorer Sport Track	1998	2005	FD21U	TK40/TK100
Falcon	1999	2005	FD3U	TK40/TK100
Focus	2000	2004	FD21U	TK40/TK100
Focus	2005	Today	FD40U	TK40/TK100
Taurus LX / SHO	1998	1999	FD21U	TK40/TK100
Territory	2004	2005	FD3U	TK40/TK100
Territory	2005	Today	FD40U	TK40/TK100
Tribute	2001	2003	FD21U	TK40/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>FORD (BR)</b> 				
C-Max	2004	2007	FC7U	TK40/TK100
Eco-Sport	2003	2007	FC7U	TK40/TK100
Fiesta	2003	Today	FC7U	TK40/TK100
Fiesta Max	2005	Today	FC7U	TK40/TK100
Focus	1998	2007	FD3U	TK40/TK100
Ka	2008	Today	FD3U	TK40/TK100
Mondeo	2006	2007	FD3U	TK40/TK100
Mondeo	2007	2011	FD40U	TK40/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>FORD (EU)</b> 				
C-Max	2003	2010	FD40U	TK40/TK100
Connect	2002	Today	FD3U	TK40/TK100
Cougar	1997	1997	FD3U	TK24/TK100
Cougar	1998	2002	FD3U	TK40/TK100
Courier	1995	Today	FD3U	TK24/TK100
Courier Kombi	1998	Today	FD3U	TK40/TK100
Escort	1995	2000	FD3U	TK24/TK100
Fiesta	1995	2002	FD3U	TK24/TK100
Fiesta	2003	2008	FD3U	TK40/TK100
Fiesta	2008	Today	FD40U	TK40/TK100
Focus	1998	2004	FD3U	TK40/TK100
Focus	2004	2010	FD40U	TK40/TK100
Fusion	2002	Today	FD3U	TK40/TK100
Galaxy	2000	2006	V66U	TK50
Galaxy	2006	2010	FD40U	TK40/TK100
Ka	1996	2008	FD3U	TK40/TK100
Ka	1996	2002	FD3U	TK24/TK100
Ka	2009	Today	FT22U	TK60/TK100
Kuga	2008	Today	FD40U	TK40/TK100
Maverick	1995	Today	NS27U	TK100
Mondeo	1995	2000	FD3U	TK24/TK100
Mondeo	2007	2011	FD40U	TK40/TK100
Puma	1997	2002	FD3U	TK24/TK100
S-Max	2006	Today	FD40U	TK40/TK100
Transit	1995	1998	FD3U	TK40/TK100
Transit	2000	Today	FD3U	TK40/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>FORD (USA)</b> 				
500	2005	Today	FD21U	TK40/TK100
Contour	1997	Today	FD21U	TK24/TK100
Crown Victoria	1998	2002	FD21U	TK24/TK100
Crown Victoria	2003	Today	FD21U	TK40/TK100
Edge	2007	Today	FD21U	TK40/TK100
Escape	2001	2007	FD21U	TK40/TK100
Escape	2008	Today	FD21U	TK40/TK100
E-Series	2008	Today	FD21U	TK40/TK100
Excursion	2000	2005	FD21U	TK40/TK100
Expedition	1997	2002	FD21U	TK24/TK100
Expedition	2003	Today	FD21U	TK40/TK100
Explorer	1998	2000	FD21U	TK24/TK100
Explorer	2000	2006	FD21U	TK40/TK100
Explorer Sport Trac	2001	2010	FD21U	TK40/TK100
F-150	1999	2003	FD21U	TK24/TK100
F-150	2004	2010	FD21U	TK40/TK100
F-250	1999	2003	FD21U	TK24/TK100
F-250	2004	Today	FD21U	TK40/TK100
F-350	2004	Today	FD21U	TK40/TK100
F-450	2008	Today	FD21U	TK40/TK100
Fiesta	2011	Today	FD21U	TK40/TK100
Five Hundred	2005	2007	FD21U	TK40/TK100
Flex	2009	Today	FD21U	TK40/TK100
Focus	2000	Today	FD21U	TK40/TK100
Freestar	2004	2007	FD21U	TK40/TK100
Freestyle	2005	2006	FD21U	TK40/TK100
Freestyle	2007	Today	FD21U	TK40/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>FORD (USA)</b> 				
Fusion	2006	Today	FD21U	TK40/TK100
GT	2005	2006	FD21U	TK24/TK100
Heavy	2000	Today	FD21U	TK24/TK100
Mustang	1996	2004	FD21U	TK24/TK100
Mustang	2005	2012	FD21U	TK40/TK100
Mustang Cobra	1996	1997	FD21U	TK40/TK100
Mustang GT	1996	1997	FD21U	TK40/TK100
Ranger	1999	2000	FD21U	TK24/TK100
Ranger	2001	2010	FD21U	TK40/TK100
Ranger XLT V6	1999	2000	FD21U	TK40/TK100
Taurus	1998	2000	FD21U	TK24/TK100
Taurus	2000	Today	FD21U	TK40/TK100
Taurus	2008	2011	FD21U	TK40/TK100
Taurus LX / SHO	1996	1999	FD21U	TK40/TK100
Thunderbird	2002	2005	FD21U	TK40/TK100
Transit Connect	2010	Today	JA2U	TK40/TK100
Windstar	1999	2000	FD21U	TK24/TK100
Windstar	2001	2003	FD21U	TK40/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>FREIGHTLINER (USA)</b> 				
Sprinter	2007	2013	MB57U	TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>GILERA (I)</b> 				
GP800	2006	Today	FT22U	TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>GM (BR)</b> 				
Corsa	1998	1999	VX1U	TK100
Zafira	1999	2000	VX1U	TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>GMC (USA)</b> 				
Acadia	2007	Today	B106U	TK60/TK100
Canyon	2008	2012	TR47U	TKM
Denali	2007	Today	B106U	TK60/TK100
Envoy	2007	Today	B106U	TK60/TK100
Savana	2008	Today	B106U	TK60/TK100
Sierra	2007	Today	B106U	TK60/TK100
Sierra	2014	2015	VX6U	TK60/TK100
Terrain	2010	Today	VX5U	TK60/TK100
Yukon	2007	Today	B106U	TK60/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>HOLDEN (AUS)</b> 				
Astra	1995	1998	VX2U	TK100
Astra	1998	2001	VX1U	TK100
Astra	2001	2004	VX1U	TK100
Astra	2004	Today	VX5U	TK60/TK100
Barina	1995	1998	VX2U	TK100
Barina	1998	2006	VX1U	TK100
Barina	2004	2006	VX5U	TK100
Barina	2006	Today	DAE48SU	TKM
Commodore	2007	Today	HC1U	TK60/TK100
Frontera	1999	Today	HD90U	TKM
Jackaroo	1999	2006	TR47SU	TKM
Rodeo	1999	2006	TR47SU	TKM
Vectra	1998	2004	VX4U	TK100
Vectra	2004	Today	VX5U	TK60/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>HONDA (AUS)</b> 				
Civic	2006	2008	HD1U	TK60/TK100
Jazz	2001	Today	HD1U	TK100
MD-X	2003	2008	HD1U	TK60/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>HONDA (J)</b> 				
Accord	1995	1999	HD90U	TK100
Accord	1995	1999	RV3U	TK100
Accord	1999	2003	HD1U	TKM
Accord	2003	2006	HD1U	TK60/TK100
Accord	2006	2008	HD1U	TKM
Accord	2008	Today	HD1U	TK60/TK100
CB1000	2011	Today	HD70U	TK60/TK100
CBF 1000	2004	Today	HD70U	TK60/TK100
CBR 1000RR Fireblade	2004	Today	HD71U	TK60/TK100
CBR 1000RR Fireblade	2007	Today	HD70U	TK60/TK100
CBR 1100F	1999	Today	HD70U	TK60/TK100
CBR 600F	1999	Today	HD70U	TK60/TK100
CBR 600RR	2003	Today	HD70U	TK60/TK100
CBR 900	2003	Today	HD70U	TK60/TK100
City	2002	2007	HD90U	TKM
Civic	1995	1999	HD90U	TK100
Civic	1996	2000	RV3U	TK100
Civic	1999	2002	HD90U	TKM
Civic	2003	2005	HD1U	TKM
Civic	2006	2008	HD1U	TK60/TK100
Civic Aerodeck	1998	2000	RV3U	TK100
Crossrunner	2011	Today	HD70U	TK60/TK100

# HORSESHOE GUIDE | GUIDA HORSESHOE

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>HONDA (J)</b> 				
Crosstourer	2012	Today	HD70U	TK60/TK100
CR-V	1997	1999	HD90U	TK100
CR-V	2000	2001	HD90U	TKM
CR-V	2002	2006	HD1U	TKM
CR-V	2007	Today	HD1U	TK60/TK100
CR-Z	2010	Today	HD1U	TK60/TK100
Edix	2004	2007	HD1U	TKM
Element	2003	Today	HD1U	TK100
FR-V	2007	Today	HD1U	TKM
Gold Wing 1800	2001	Today	HD72U	TK60/TK100
Hornet	2003	Today	HD70U	TK60/TK100
HR-V	2000	2005	HD90U	TKM
Insight	2000	2005	HD90U	TKM
Insight	2009	Today	HD1U	TK60/TK100
Integra	1998	2001	HD90U	TK100
Integra	2012	Today	HD70U	TK60/TK100
Jazz	2001	2007	HD1U	TKM
Jazz	2006	Today	HD1U	TKM
Jazz	2008	Today	HD1U	TK60/TK100
Legend	1997	2004	HD90U	TK100
Legend	2007	Today	HD1U	TKM
Logo	1999	Today	HD90U	TKM
NC700 S	2012	Today	HD70U	TK60/TK100
NC700 X	2012	Today	HD70U	TK60/TK100
NSX	1997	2005	HD90U	TK100
NT 650V	1999	Today	HD70U	TK60/TK100
Odyssey	1998	Today	HD90U	TK100
Passport	1998	Today	HD90U	TK100
Pilot	2003	Today	HD1U	TK100
Prelude	1995	2001	HD90U	TK100
S2000	2000	2003	HD1U	TKM
S2000	2004	2005	HD1U	TKM
S2000	2006	Today	HD1U	TKM
SH 300	2006	Today	ZAD20U	TK60/TK100
Shadow 750	2004	Today	HD70U	TK60/TK100
Shadow Spirit 750	2004	Today	HD70U	TK60/TK100
Shuttle	1995	2000	HD90U	TK100
Shuttle	2001	Today	HD90U	TKM
Silver Wing	2001	Today	HD70U	TK60/TK100
ST1300 PAN	2008	Today	HD70U	TK60/TK100
Stream	2001	2003	HD90U	TKM
Stream	2003	2007	HD1U	TKM
Stream	2008	Today	HD1U	TK60/TK100
SW-T 400	2009	Today	HD70U	TK60/TK100
SW-T 600	2011	Today	HD70U	TK60/TK100
Transalp 700	2008	Today	HD70U	TK60/TK100
Varadero	2003	Today	HD70U	TK60/TK100
VFR 1200	2009	Today	HD70U	TK60/TK100
VT 750 C4	2004	Today	HD70U	TK60/TK100
VTX1800	2002	Today	HD70U	TK60/TK100
X11	2001	Today	HD70U	TK60/TK100






MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>HONDA (USA)</b> 				
Accord	1998	2002	HD90U	TK100
Accord	2003	Today	HD1U	TK60/TK100
Accord Crosstour	2010	Today	HD1U	TK60/TK100
Civic	2001	2002	HD90U	TK100
Civic	2003	2005	HD1U	TK100
Civic	2006	Today	HD1U	TK60/TK100
CR-V	2002	2006	HD1U	TK100
CR-V	2007	Today	HD1U	TK60/TK100
CR-Z	2011	Today	HD1U	TK60/TK100
Element	2003	2005	HD1U	TK100
Element	2006	2011	HD1U	TK60/TK100
Fit	2007	Today	HD1U	TKM
Fit	2009	Today	HD1U	TK60/TK100
Insight	2000	2006	HD90U	TK100
Insight	2010	Today	HD1U	TK60/TK100
Odyssey	1998	2002	HD90U	TK100
Odyssey	2003	2004	HD1U	TK100
Odyssey	2005	Today	HD1U	TK60/TK100
Pilot	2003	2005	HD1U	TK100
Pilot	2006	Today	HD1U	TK60/TK100
Prelude	1997	2002	HD90U	TK100
Ridgeline	2006	Today	HD1U	TK60/TK100
S2000	2000	2003	HD90U	TK100
S2000	2004	2005	HD1U	TK100
S2000	2006	Today	HD1U	TKM




MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>HUMMER (USA)</b> 				
H2	2008	Today	B106U	TK60/TK100
H2 Sut	2008	Today	B106U	TK60/TK100
H3	2008	Today	B106U	TK60/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>HYUNDAI (ROK)</b> 				
Accent	1996	1999	HY10U	TK24/TK100
Accent	1999	2011	HY6U	TK60/TK100
Accent	2011	Today	HY20U	TK100
Atos	1997	2000	HY10U	TK24/TK100
Atos Prime	1999	2001	HY10U	TK24/TK100
Atos Prime	2003	Today	HY10U	TK60/TK100
Azera	2006	2010	TR49U	TK60/TK100
Coupé	1996	2002	HY6U	TK24/TK100
Coupé	2002	Today	HY6U	TK60/TK100
Elantra	1996	2000	HY6U	TK24/TK100
Elantra	2000	2007	HY6U	TK60/TK100
Elantra	2007	Today	HY14SU	TK60/TK100
Elantra neos	2007	Today	TR49U	TK60/TK100
Entourage	2007	2009	HY14U	TK60/TK100
Excel	1996	1999	HY10U	TK24/TK100
Excel	1999	Today	HY6U	TK60/TK100
Galloper	1999	2003	HY6U	TK24/TK100
Genesis	2009	Today	TR49U	TK60/TK100
Getz	2002	Today	HY6U	TK60/TK100
Grandeur	2006	Today	TR49U	TK60/TK100
Grandeur XG (AUS)	1998	2005	HY7SU	TK40/TK100
H-1	1999	Today	HY6U	TK24/TK100
H-1	2006	Today	HY6U	TK60/TK100
H-1 Bus	2008	Today	HY14U	TK60/TK100
i10	2008	Today	HY14U	TK60/TK100
i20	2008	Today	TR49U	TK60/TK100
i45	2009	Today	TR49U	TK60/TK100
Innovation	1999	2003	HY6U	TK24/TK100
ix20	2010	Today	TR49U	TK60/TK100
ix35	2010	Today	TR49U	TK60/TK100
Lantra	1996	2000	HY6U	TK24/TK100
Lavita	2001	Today	HY6U	TK60/TK100
Matrix	2002	Today	HY6U	TK60/TK100
Picanto	2012	Today	HY21U	TK40/TK100
Pony	1995	1999	HY10U	TK24/TK100
Santa Fe	2000	2002	HY7SU	TK40/TK100
Santa Fe	2001	2006	HY6U	TK60/TK100
Santa Fe	2006	Today	HY14SU	TK60/TK100
Santamo	1999	2003	HY6U	TK24/TK100
Scoupe	1996	Today	HY6U	TK24/TK100
Some models	2004	Today	HY12U	TK40/TK100
Sonata	1996	1998	HY7SU	TK24/TK100
Sonata	1998	2004	HY7SU	TK40/TK100
Sonata	2005	Today	HY14SU	TK60/TK100
Sonica	1996	1999	HY7SU	TK24/TK100
Sonica	1999	2004	HY7SU	TK40/TK100
Starex	1998	Today	HY12U	TK24/TK100
Terracan	2001	2007	HY6U	TK60/TK100
Terracan	2001	2006	HY10U	TK60/TK100
Tiburon	2001	Today	HY6U	TK60/TK100
Trajet	2000	2006	HY7SU	TK40/TK100
Tucson	2005	Today	HY6U	TK60/TK100
Veracruz	2007	Today	HY14SU	TK60/TK100
Verna	1996	1999	HY10U	TK24/TK100
Verna	1999	Today	HY6U	TK60/TK100
Verna Fluidic	2011	Today	HY20U	TK100
XG25 / XG30	1998	2005	HY7SU	TK40/TK100
XG300 (Canada)	1998	2005	HY7SU	TK40/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>HYUNDAI (USA)</b> 				
Accent (Canada)	2008	Today	HY12U	TK60/TK100
Accent	2012	Today	HY21U	TK60/TK100
Azera	2006	Today	TR49U	TK60/TK100
Elantra	1996	2000	HY6U	TK24/TK100
Elantra (Canada)	2006	Today	HY12U	TK60/TK100
Elantra Touring	2009	Today	TR49U	TK60/TK100
i30	2007	Today	TR49U	TK60/TK100
Santa Fe (Canada)	2007	2009	HY14SU	TK60/TK100
Santa Fe	2013	Today	HY21SU	TK100
Sonata (Canada)	2008	2010	HY14SU	TK60/TK100
Tiburon (Canada)	2002	2009	HY12U	TK60/TK100
Tucson (Canada)	2008	Today	HY12U	TK60/TK100
Veracruz (Canada)	2007	2011	HY14SU	TK60/TK100
Velostar	2012	Today	HY21U	TK60/TK100
XG300 (Canada)	2001	2003	HU14U	TK60/TK100
XG300 (Canada)	2001	2003	HY7SU	TK60/TK100
XG350 (Canada)	2001	2005	HY7SU	TK60/TK100
XG350 (Canada)	2001	2005	HU14U	TK60/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>INFINITI (J)</b> 				
FX35	2003	2008	NS34U	TK60/TK100
FX45	2003	2008	NS34U	TK60/TK100
G20	2000	2002	NS34U	TK40/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>INFINITI (J)</b> 				
G35 / G35 Coupè	2003	2007	NS34U	TK60/TK100
I30	1995	1999	NS27U	TK100
I30	2000	2004	NS27U	TK40/TK100
I35	2000	2004	NS27U	TK40/TK100
M35	2003	2006	NS34U	TK60/TK100
M45	2003	2006	NS34U	TK60/TK100
Q45	1995	1997	NS34U	TK100
Q45	1997	2000	NS34U	TK40/TK100
Q45	2001	2005	NS34U	TK60/TK100
QX4	1995	1998	NS34U	TK100
QX4	1997	1999	NS34U	TK40/TK100
QX4	1999	2004	NS27U	TK40/TK100
QX56	2004	2007	NS34U	TK60/TK100
QXA	1999	2003	NS34U	TK40/TK100
<b>INFINITI (USA)</b> 				
G35	2003	2007	NS34U	TKM
<b>ISUZU (J)</b> 				
700P	2007	Today	ISU5U	TK60/TK100
Ascender	2003	Today	HD90U	TKM
Axiom	2003	2006	HD90U	TKM
Big Horn	1998	2002	SU15U	TK40/TK100
D-Max	1999	2006	HD90U	TKM
D-Max	2007	Today	TR47SU	TK60/TK100
ELF	2007	Today	ISU5U	TK60/TK100
i-280 / i-350	2006	Today	HD90U	TKM
i-290 / i-370	2007	Today	HD90U	TKM
NPR	2007	Today	ISU5U	TK60/TK100
Rodeo	1999	2006	HD90U	TKM
Trooper	1998	2002	SU15U	TK40/TK100
<b>IVECO (I)</b> 				
35C11	2000	Today	FT50U	TK60/TK100
Daily	2005	Today	FT50U	TK60/TK100
Eurocargo	2002	2007	FT22U	TK60/TK100
Eurocargo	2008	Today	FT22U	TK40/TK100
Eurostar	1998	Today	FT50U	TK60/TK100
New Daily	1998	Today	FT50U	TK60/TK100
S-2000	1998	Today	FT50U	TK60/TK100
Stralis	2002	2007	FT22U	TK60/TK100
Stralis	2008	Today	FT22U	TK40/TK100
<b>JAGUAR (GB)</b> 				
S-Type	1999	2000	FD3U	TK40/TK100
S-Type	2000	2006	JA2U	TK40/TK100
XJ8	2004	2009	JA2U	TK40/TK100
XJ8	2000	2003	JA2U	TKM
XJ-Type	2004	2006	JA2U	TK40/TK100
XJR	2000	2003	JA2U	TKM
XK8	2000	2006	JA2U	TKM
XKR	2000	2006	JA2U	TKM
XLR	2004	2009	JA2U	TK40/TK100
X-Type	2002	Today	JA2U	TK40/TK100
<b>JEEP (USA)</b> 				
Cherokee	1999	2005	Y160U	TK40/TK100
Cherokee	2005	Today	Y160U	TK60/TK100
Cherokee Limited	1999	2005	Y160U	TK40/TK100
CJ5, CJ7	2006	Today	Y160U	TK60/TK100
CJ5, CJ7	1998	2005	Y160U	TK40/TK100
Comanche	2006	Today	Y160U	TK60/TK100
Commander	2006	2007	Y160U	TK60/TK100
Commander	2008	2010	Y170U	TK60/TK100
Compass	2007	Today	Y160U	TK60/TK100
G. Cherokee Lux	1999	2005	Y160U	TK40/TK100
G. Cherokee Sport	1998	2004	Y160U	TK40/TK100
Grand Cherokee	1999	2005	Y160U	TK40/TK100
Grand Cherokee	2005	2007	Y160U	TK60/TK100
Grand Cherokee	2008	Today	Y170U	TK60/TK100
Liberty	2002	2004	Y160U	TK40/TK100
Liberty	2005	Today	Y160U	TK60/TK100
Patriot	2007	Today	Y160U	TK60/TK100
Wrangler	1998	2006	Y160U	TK40/TK100
Wrangler	2007	Today	Y160U	TK60/TK100
<b>KAWASAKI (J)</b> 				
Ninja ZX-10R	2004	2010	KAW12SU	TK40/TK100
Ninja ZX-6R	2006	Today	KAW12SU	TK40/TK100
VN	2006	Today	KAW12SU	TK40/TK100
Z-1000	2004	Today	KAW12SU	TK40/TK100
Z-750	2006	Today	KAW12SU	TK40/TK100
ZZR 1400	2007	Today	KAW12SU	TK40/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>KIA (ROK)</b> 				
Amanti	2004	Today	TR49U	TK40/TK100
Carens	2000	2006	KI3SU	TK60/TK100
Carens	2001	2006	KI3SU	TK40/TK100
Carens	2006	Today	HY14U	TK60/TK100
Carnival	1999	2000	KI3SU	TKM
Carnival	2000	2002	KI3SU	TK40/TK100
Carnival	2002	2005	KI3SU	TK60/TK100
Carnival	2005	Today	HY14U	TK60/TK100
Cee'd / Cee'd SW	2007	Today	TR49U	TK60/TK100
Ceed	2008	Today	KI22U	TK60/TK100
Clarence	2000	2005	KI3SU	TK40/TK100
Clarus	1998	2001	KI3SU	TKM
Forte	2008	2011	HY14SU	TK60/TK100
Joice	2000	2004	KI3SU	TK40/TK100
Magentis	2001	2006	KI3SU	TK60/TK100
Magentis	2006	Today	HY14SU	TK60/TK100
Mentor	2002	2004	KI3SU	TK60/TK100
Morning	2006	Today	HY6U	TK60/TK100
Optima	2001	2006	KI3SU	TK60/TK100
Optima	2007	Today	HY14U	TK60/TK100
Optima	2011	Today	KI22U	TK60/TK100
Picanto	2004	2008	HY6U	TK60/TK100
Picanto	2008	2011	TR49U	TK60/TK100
Pride	1999	2001	KI3SU	TKM
Rio	2001	2005	KI3SU	TK40/TK100
Rio	2006	Today	HY14U	TK60/TK100
Sedona	1999	2000	KI3SU	TKM
Sedona	2002	2005	KI3SU	TK60/TK100
Sedona	2005	Today	HY14U	TK60/TK100
Sephia	2002	2004	KI3SU	TK60/TK100
Shuma	1998	2001	KI3SU	TKM
Shuma	2000	2001	KI3SU	TK40/TK100
Sorento	2002	2009	HY7SU	TK60/TK100
Sorento	2010	Today	TR49U	TK60/TK100
Soul	2009	Today	HY14SU	TK60/TK100
Sportage	1999	2001	KI3SU	TKM
Sportage	2001	2005	KI3SU	TK40/TK100
Sportage	2005	Today	HY6U	TK60/TK100
<b>KIA (USA)</b> 				
Amanti	2007	2009	TR49U	TK60/TK100
Borrego	2009	2010	TR49U	TK60/TK100
Sedona (Canada)	2006	2009	HY14SU	TK60/TK100
Sorento (Canada)	2004	2005	HY7SU	TK40/TK100
Sorento (Canada)	2006	2009	HY7SU	TK60/TK100
<b>LANCIA (I)</b> 				
Delta	2008	Today	FT22U	TK60/TK100
K	1995	2001	AR20U	TK100
K Coupè	1997	2001	AR20U	TK100
Lybra	1999	Today	FT22U	TKM
Musa	2004	2009	FT22U	TKM
Musa	2009	Today	FT22U	TK60/TK100
Phedra	2002	Today	PG83U	TK60/TK100
Thesis	1998	Today	FT22U	TKM
Y	2003	2010	FT22U	TKM
Y	2011	Today	FT22U	TK60/TK100
Z	1998	Today	CN22U	TK100
<b>LAND ROVER (GB)</b> 				
Discovery 3	2006	2009	FD40U	TK60/TK100
LR3	2005	2009	FD40U	TK60/TK100
Range Rover	2005	2009	FD40U	TK40/TK100
Range Rover Sport	2006	Today	FD40U	TK60/TK100
<b>LEXUS (J)</b> 				
Altezza (J)	1999	Today	TR48U	TK40/TK100
Celsior (J)	1997	Today	TR49U	TK40/TK100
CT200H	2011	Today	TR49U	TKM
ES 300-330	1997	2003	TR48U	TK24/TK100
ES 300-330	2002	2003	TR48U	TK40/TK100
ES 300-330	2004	2007	TR48U	TK40/TK100
ES350	2006	Today	TR48U	TK40/TK100
GS / LS / LX	1998	Today	TR48U	TK40/TK100
GS series	1997	2003	TR48U	TK24/TK100
GS300	2005	2007	TR48U	TK40/TK100
GS300 / GS400 (J)	1998	Today	TR48U	TK40/TK100
GS300/400	1998	2005	TR48U	TK40/TK100
GS430	2001	2005	TR48U	TK40/TK100
GS430	2005	2007	TR48U	TK40/TK100
GS450h	2006	-	TR48U	TK40/TK100
GX470	2003	2007	TR48U	TK40/TK100
HS250h	2009	Today	TR49U	TKM



# HORSESHOE GUIDE | GUIDA HORSESHOE


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>LEXUS (J)</b> 				
IS series	1999	2003	TR48U	TK24/TK100
IS200	1999	2005	TR48U	TK40/TK100
IS220	2006	-	TR48U	TK40/TK100
IS250	2006	-	TR48U	TK40/TK100
IS300	2001	2005	TR48U	TK40/TK100
IS350	2006	-	TR48U	TK40/TK100
LS series	1997	2003	TR48U	TK24/TK100
LS200	1999	-	TR48U	TK40/TK100
LS400	1999	2003	TR48U	TK40/TK100
LS430	2001	2004	TR48U	TK40/TK100
LX series	1997	2003	TR48U	TK24/TK100
LX470	2001	2002	TR48U	TK40/TK100
LX470	2003	2006	TR48U	TK40/TK100
RX series	1998	2003	TR48U	TK24/TK100
RX300	1999	2003	TR48U	TK40/TK100
RX330	2003	2006	TR48U	TK40/TK100
RX350	2004	2010	TR48U	TK40/TK100
RX400h	2005	2009	TR48U	TK40/TK100
RX450h	2010	Today	TR49U	TKM
SC series	1997	2003	TR48U	TK24/TK100
SC430	2002	2010	TR48U	TK40/TK100



MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>LINCOLN (USA)</b> 				
Aviator	2003	2007	FD21U	TK40/TK100
Blackwood	2002	2003	FD21U	TK24/TK100
Continental	1998	2002	FD21U	TK24/TK100
Continental	1998	2004	FD21U	TK40/TK100
LHS	1998	Today	FD21U	TK40/TK100
LS	2000	2006	FD21U	TK40/TK100
Mark LT	2005	2009	FD21U	TK40/TK100
Mark VIII	1997	1998	FD21U	TK40/TK100
MKX	2007	Today	FD21U	TK40/TK100
MKZ	2006	Today	FD21U	TK40/TK100
Navigator	1997	2002	FD21U	TK24/TK100
Navigator	2003	Today	FD21U	TK40/TK100
Town & Country	1997	2002	FD21U	TK24/TK100
Town Car	1998	2002	FD21U	TK40/TK100
Town Car	2003	Today	FD21U	TK40/TK100
Zephyr	2006	Today	FD21U	TK40/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>MAHINDRA</b> 				
Bolero	2011	Today	MH1U	TK60/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>MARUTI SUZUKI</b> 				
Alto	2007	2010	SU17SU	TK40/TK100
Alto K10	2010	Today	SU19U	TK60/TK100
A-Star	2007	Today	SU19U	TK60/TK100
Ritz	2007	Today	SU19U	TK60/TK100
Swift	2007	Today	SU19U	TK60/TK100
SX4	2007	Today	SU19U	TK60/TK100
Versa	2007	2010	SU17U	TK40/TK100
Wagon R	2007	2010	SU17U	TK40/TK100
Wagon R	2010	Today	SU19U	TK60/TK100
Zen Estilo	2007	2010	SU17U	TK40/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>MASERATI (I)</b> 				
GranSport	2004	2007	FT22U	TKM
GranTurismo	2007	2012	FT22U	TKM
Quattroporte	2003	2012	FT22U	TKM


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>MAZDA (EU)</b> 				
121	1997	Today	FD3U	TK24/TK100
323	1998	2000	MZ24U	TK100
626 (ES, LS, LUX)	1998	1999	MZ24U	TK100
B Series P/U (USA)	2001	2006	FD21U	TK40/TK100
CX-7	2007	Today	MZ24U	TK40/TK100
CX-9	2007	Today	MZ24U	TK40/TK100
Demio (J)	2003	Today	MZ24U	TK40/TK100
Mazda 2	2002	2006	MZ24U	TK40/TK100
Mazda 2	2007	Today	MZ24U	TK40/TK100
Mazda 3	2003	2009	MZ24U	TK40/TK100
Mazda 3	2010	Today	MZ24U	TK40/TK100
Mazda 5	2005	2011	MZ24U	TK40/TK100
Mazda 5	2012	Today	MZ24U	TK40/TK100
Mazda 6	2002	2007	MZ24U	TK40/TK100
Miata (USA)	2005	Today	MZ24U	TK40/TK100
MPV (USA)	2005	Today	MZ24U	TK40/TK100
MX-5	1998	2000	MZ24U	TK100
MX-5	2005	Today	MZ24U	TK40/TK100
Pickup	1999	2001	FD21U	TK24/TK100
RX-8	2004	Today	MZ24U	TK40/TK100
Tribute (USA)	2001	Today	FD21U	TK40/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>MERCEDES (D)</b> 				
Sprinter	2007	2013	MB57U	TK100
<b>MERCURY (USA)</b> 				
Cougar	1999	2002	FD20U	TK24/TK100
Grand Marquis	1998	2003	FD21U	TK24/TK100
Grand Marquis	2003	2010	FD21U	TK40/TK100
Marauder	2003	2005	FD21U	TK40/TK100
Mariner	2005	2006	FD21U	TK40/TK100
Mariner	2005	2007	FD21U	TK40/TK100
Milan	2006	Today	FD21U	TK40/TK100
Montego	2005	2007	FD21U	TK40/TK100
Monterey	2004	2007	FD21U	TK40/TK100
Mountaineer	1998	2001	FD21U	TK24/TK100
Mountaineer	2001	2010	FD21U	TK40/TK100
Mystique	1997	2000	FD20U	TK40/TK100
Sable	1996	2000	FD21U	TK24/TK100
Sable	2000	2007	FD21U	TK40/TK100
Sable	2008	Today	FD21U	TK40/TK100
Sable GS	1999	2000	FD21U	TK40/TK100
Sable GS/LS	2000	2007	FD21U	TK40/TK100
Sable LS/SE/SHO	1996	2000	FD21U	TK40/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>MITSUBISHI (J)</b> 				
380	2006	Today	MT8SU	TK60/TK100
ASX	2010	Today	MT8SU	TK60/TK100
Challenger	1999	Today	MT1U	TK40/TK100
Colt	1996	2003	MT8SU	TK24/TK100
Colt	2004	Today	MT15U	TK60/TK100
Diamante	1996	2000	MT8SU	TK24/TK100
Diamante	2000	2004	MT1U	TK40/TK100
Diamante	2001	2003	MT1U	TK40/TK100
Eclipse	1996	2000	MT1U	TK24/TK100
Eclipse	2000	2001	MT11U	TK40/TK100
Eclipse	2002	2003	MT1U	TK40/TK100
Express	1996	Today	MT1U	TK40/TK100
Focus	1996	Today	MT1U	TK24/TK100
Galant	1996	2005	MT1U	TK40/TK100
Galant	1996	2000	MT1U	TK24/TK100
Galant	2000	2001	MT11U	TK40/TK100
Grandis	2003	Today	MT8SU	TK60/TK100
I-MiEV	2010	Today	MT8SU	TK60/TK100
L200	2002	2006	MT1U	TK40/TK100
L200	2006	Today	MT1U	TK60/TK100
Lancer	1996	2003	MT8SU	TK24/TK100
Lancer	2003	2006	MT8SU	TK40/TK100
Lancer	2006	Today	MT8SU	TK60/TK100
Magna	1999	2005	TR49U	TK60/TK100
Mirage	1996	2002	MT8SU	TK40/TK100
Montero	1996	2002	MT1U	TK40/TK100
Montero	2000	2002	MT1U	TK40/TK100
Montero	2002	2005	MT1U	TK40/TK100
Montero IO	2000	Today	MT8SU	TK40/TK100
Montero Sport	2000	2005	MT1U	TK40/TK100
Nativa	2001	2002	MT1U	TK40/TK100
Nimbus	1998	1999	MT1U	TK24/TK100
Nimbus	1998	1999	MT1U	TK40/TK100
Outlander	2000	2003	MT1U	TK40/TK100
Outlander	2004	2006	MT8SU	TK40/TK100
Outlander	2006	Today	MT8SU	TK60/TK100
Pajero	1996	2000	MT1U	TK24/TK100
Pajero	2000	2002	MT1U	TK40/TK100
Pajero	2002	2006	MT1U	TK40/TK100
Pajero	2006	Today	MT1U	TK60/TK100
Pajero IO	1999	Today	MT8SU	TK40/TK100
Pajero Mini (J)	1999	Today	MT8SU	TK40/TK100
Pajero Pinin	1999	Today	MT8SU	TK40/TK100
Pajero Sport	1999	2006	MT1U	TK40/TK100
Raider	2006	2009	MT11U	TK40/TK100
Shogun	1996	2005	MT1U	TK40/TK100
Shogun Pinin	1999	Today	MT8SU	TK40/TK100
Shogun Sport	1999	2003	MT1U	TK40/TK100
Space Gear	1996	Today	MT1U	TK24/TK100
Space Runner	1996	1999	MT1U	TK24/TK100
Space Star	1999	2005	MT1U	TK60/TK100
Space Wagon	1998	Today	MT1U	TK40/TK100
Triton	1999	Today	MT1U	TK40/TK100
Verada	2002	2003	MT1U	TK40/TK100
Verada (AUS)	2000	2002	TR49U	TK60/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>MITSUBISHI (USA)</b> 				
Eclipse	2000	2005	MT11U	TK40/TK100
Eclipse	2006	2007	MT8SU	TK60/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>MITSUBISHI (USA)</b> 				
Eclipse	2007	Today	MT8SU	TK60/TK100
Endeavor	2006	2007	MT11U	TK60/TK100
Endeavor	2007	2011	MT8SU	TK60/TK100
Galant	2000	2003	MT11U	TK40/TK100
Galant	2004	2006	MT11U	TK60/TK100
Galant	2006	Today	MT8SU	TK60/TK100
Lancer	2003	2007	MT8SU	TK40/TK100
Lancer	2007	2010	MT8SU	TK60/TK100
Raider	2006	2009	Y160U	TK60/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>MOTO GUZZI (I)</b> 				
Bellagio	2006	Today	ZAD30U	TK100
Grisio	2006	Today	ZAD30U	TK100
Norge	2006	Today	ZAD30U	TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>NISSAN (J)</b> 				
350-Z	2003	Today	NS34U	TK40/TK100
350-Z (USA)	2003	2009	NS34U	TK60/TK100
Almera	1995	1998	NS27U	TK100
Almera	1999	2000	NS34U	TK50
Almera	2000	Today	NS34U	TK40/TK100
Almera Tino	1999	2004	NS34U	TK40/TK100
Almera Tino	2004	2006	NS34U	TK60/TK100
Altima	2000	2004	NS34U	TK40/TK100
Altima (USA)	2005	2006	NS34U	TK60/TK100
Armada (USA)	2008	Today	NS34U	TK60/TK100
Atleon	2002	Today	NS27U	TK40/TK100
Cab Star	2000	Today	NS27U	TK40/TK100
Cube (USA)	2009	Today	NS34U	TK60/TK100
Frontier (USA)	2002	2005	NS34U	TK40/TK100
Frontier (USA)	2006	2008	NS34U	TK60/TK100
Interstar	2002	2003	RN30U	TK100
Interstar	2002	Today	RN30U	TK60/TK100
Juke	2010	Today	NS34U	TK60/TK100
Lavina (USA)	2007	Today	NS34U	TK60/TK100
Maxima	1995	1999	NS27U	TK100
Maxima	2000	2003	NS34U	TK40/TK100
Maxima	2000	2003	NS27U	TK50
Maxima (USA)	2000	2003	NS34U	TK40/TK100
Maxima (USA)	2004	2007	NS34U	TK60/TK100
Micra	1996	1998	NS27U	TK100
Micra	1999	2000	NS27U	TK50
Micra	2003	2006	NS27U	TK60/TK100
Micra	2007	Today	NS34U	TK60/TK100
Micra March (J)	2000	Today	NS27U	TK40/TK100
Murano	2003	2008	NS34U	TK60/TK100
Murano	2003	Today	NS34U	TK40/TK100
Navara	2000	2003	NS34U	TK50
Navara	2003	Today	NS34U	TK40/TK100
Navara DC	2005	Today	NS34U	TK60/TK100
Note	2006	Today	NS34U	TK60/TK100
NP300	2010	Today	NS34U	TK60/TK100
NV Series (USA)	2012	Today	NS34U	TK60/TK100
Pathfinder	2000	2004	NS34U	TK40/TK100
Pathfinder (USA)	2005	Today	NS34U	TK60/TK100
Patrol	1998	2003	NS34U	TK50
Patrol	2004	Today	NS34U	TK40/TK100
Pixo	2010	Today	SU20U	TK60/TK100
Primastar	2003	Today	RN30U	TK60/TK100
Primera	1995	1996	NS27U	TK100
Primera	1997	1997	NS34U	TK100
Primera	1998	2000	NS34U	TK40/TK100
Primera	2001	2002	NS34U	TK50
Primera	2002	Today	NS34U	TK60/TK100
Pulsar	1995	1996	NS27U	TK100
Pulsar	1997	1998	NS34U	TK100
Pulsar	1999	2000	NS34U	TK40/TK100
Pulsar	2001	Today	NS34U	TK50
Qashqai	2006	Today	NS34U	TK60/TK100
Quest (USA)	2004	2010	NS34U	TK60/TK100
Quest (USA)	2004	2008	NS34U	TK60/TK100
Rouge (USA)	2008	Today	NS34U	TK60/TK100
Sentra	2000	2006	NS34U	TK40/TK100
Sentra (USA)	2007	Today	NS34U	TK60/TK100
Serena	1996	1998	NS27U	TK100
Serena	1998	Today	NS27U	TK50
Stanza (USA)	2007	2008	NS34U	TK60/TK100
Terrano II	1995	1998	NS27U	TK100
Terrano II	1999	2001	NS27U	TK50
Terrano II	2002	2006	NS27U	TK40/TK100
Tiida (USA)	2007	Today	NS34U	TK60/TK100
Titan (USA)	2004	Today	NS34U	TK60/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>NISSAN (J)</b> 				
Vanette	1996	1999	NS27U	TK100
Vanette	1999	Today	NS27U	TK50
Vanette Cargo	1999	2000	NS27U	TK50
Vanette Cargo	2000	Today	NS27U	TK40/TK100
Versa (USA)	2007	Today	NS34U	TK60/TK100
X-Terra	2000	2004	NS34U	TK40/TK100
Xterra (USA)	2005	2008	NS34U	TK60/TK100
X-Trail	1998	2000	NS34U	TK50
X-Trail	2001	2007	NS34U	TK40/TK100
X-Trail	2007	Today	NS34U	TK60/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>OPEL (D)</b> 				
Agila	2004	Today	VX5U	TK100
Agila	2008	Today	SU19U	TK60/TK100
Antara	2007	Today	OPL1U	TK60/TK100
Astra	1995	1998	VX2U	TK100
Astra	1999	2001	VX1U	TK100
Astra	1999	2001	VX2U	TK100
Astra	2001	2004	VX1U	TK100
Astra / Astra SW	2004	Today	VX5U	TK60/TK100
Calibra	1995	1998	VX3U	TK100
Calibra	1995	1998	VX4U	TK100
Combo	1998	2002	RN30U	TK100
Combo	2002	2004	VX1U	TK100
Combo	2004	Today	VX5U	TK100
Corsa	1995	1998	VX2U	TK100
Corsa	1999	2000	VX1U	TK100
Corsa	1999	2000	VX2U	TK100
Corsa	2000	2004	VX1U	TK100
Corsa	2004	Today	VX5U	TK100
Corsa	2006	Today	VX5U	TK60/TK100
Frontera	2000	Today	HD90U	TKM
GT Cabriolet	2008	Today	B106U	TK60/TK100
Insignia	2008	Today	VX5U	TK60/TK100
Meriva	2002	2004	VX1U	TK100
Meriva	2004	2010	VX5U	TK100
Meriva	2010	Today	VX5U	TK60/TK100
Movano	1998	2002	RN30U	TK100
Movano	2002	2010	RN30U	TK60/TK100
Movano	2011	Today	PG33U	TK60/TK100
Omega	1995	1999	VX3U	TK100
Omega	1995	1999	VX4U	TK100
Omega	1999	2000	VX1U	TK100
Omega	1999	2000	VX2U	TK100
Signum	2003	Today	VX5U	TK60/TK100
Sintra	1997	Today	VX4U	TK100
Speedster	2001	Today	VX1U	TK100
Tigra	1995	1997	VX2U	TK100
Tigra	1998	2001	VX2U	TK100
Tigra	1998	2001	VX1U	TK100
Tigra	2001	2004	VX1U	TK100
Tigra	2004	Today	VX5U	TK100
Vectra	1995	1998	VX3U	TK100
Vectra	1995	1998	VX4U	TK100
Vectra	1998	2002	VX4U	TK100
Vectra	2004	Today	VX5U	TK60/TK100
Vivaro	2002	Today	RN30U	TK60/TK100
Zafira	1999	2001	VX4U	TK100
Zafira	2001	2005	VX1U	TK100
Zafira	2006	Today	VX5U	TK60/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>PEUGEOT (F)</b> 				
1007	2005	Today	PG33U	TK60/TK100
106	1997	2000	RN30U	TK100
106	2000	2004	RN30U	TK60/TK100
107	2005	Today	PG33U	TK40/TK100
206	1998	2001	RN30U	TK50
206	2001	2009	RN30U	TK60/TK100
206 Cabrio	2001	2002	RN30U	TK50
206 Cabrio	2002	Today	RN30U	TK60/TK100
206 Plus	2008	Today	RN30U	TK60/TK100
207	2006	Today	PG83U	TK60/TK100
208	2012	Today	PG83U	TK60/TK100
3008	2009	Today	PG83U	TK60/TK100
306	1997	Today	RN30U	TK100
307 / 307 S. Wagon	2001	Today	PG83U	TK60/TK100
308	2007	Today	PG83U	TK60/TK100
4007	2007	Today	MT8SU	TK60/TK100
406	1997	1999	PG31U	TK100
406	1999	2002	PG31U	TK50
406	2002	2004	PG31U	TK60/TK100
407	2004	2011	PG33U	TK60/TK100

# HORSESHOE GUIDE | GUIDA HORSESHOE

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>PEUGEOT (F)</b> 				
407 / 407 S. Wagon	2004	Today	PG33U	TK60/TK100
5008	2009	Today	PG83U	TK60/TK100
508	2012	Today	PG33U	TK60/TK100
607	2004	2010	PG31U	TK60/TK100
806	1998	Today	CN22U	TK100
807	2002	Today	PG83U	TK60/TK100
Bipper	2009	Today	FT22U	TK60/TK100
Boxer	2006	Today	FT22U	TK60/TK100
Expert	1997	2001	CN22U	TK100
Expert	2007	Today	PG83U	TK60/TK100
ION	2011	Today	MT8SU	TK60/TK100
Partner	1998	2000	CN22U	TK100
Partner	2001	2002	CN22U	TK60/TK100
Partner	2002	Today	PG33U	TK60/TK100
Ranch	1998	2000	CN22U	TK100
Ranch	2001	2002	CN22U	TK60/TK100
Ranch	2002	2007	PG33U	TK60/TK100
RCZ	2010	Today	PG83U	TK60/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>PIAGGIO (I)</b> 				
MP3	2006	Today	FT22U	TK100
X8	2006	Today	FT22U	TK100
Xevo 400	2006	Today	FT22U	TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>PLYMOUTH (USA)</b> 				
Breeze	1999	2001	Y160U	TK40/TK100
Neon	2000	2005	Y160U	TK40/TK100
Prowler	2000	Today	Y160U	TK40/TK100
Voyager	2001	2003	Y160U	TK40/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>PONTIAC (USA)</b> 				
G3	2010	Today	DAE48SU	TKM
G5	2007	2009	B106U	TK60/TK100
G5 Pursuit (Canada)	2005	2010	B106U	TK60/TK100
G5 Pursuit (Canada)	2005	Today	B106U	TK60/TK100
G6	2004	2010	B106U	TK60/TK100
G8	2008	Today	B106U	TK60/TK100
Solstice	2006	2009	B106U	TK60/TK100
Torrent	2006	2009	B106U	TK60/TK100
Vibe	2009	2010	TR47U	TK40/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>PORSCHE (D)</b> 				
911	1998	1999	V66U	TK100
911	2000	Today	V66U	TKM
Boxster	1996	1998	V66U	TK100
Boxster	1999	Today	V66U	TKM
Cayenne	2006	Today	V66U	TK60/TK100
Cayman	2009	Today	V66U	TK60/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>PROTON (MAL)</b> 				
Exora	2009	Today	MT1U	TKM
Gen-2	2004	2011	MT1U	TKM
Inspira	2010	Today	MT8SU	TKM
Persona	2007	2010	MT1U	TKM
Saga BLM	2008	2010	MT8SU	TKM
Saga FLX	2011	Today	MT1U	TKM
Satria NEO	2006	Today	MT1U	TKM


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>RENAULT (F)</b> 				
Avantime	2001	2003	RN30U	TK40/TK100
Clio	1995	2001	VE20U	TK100
Clio	1995	2001	RN30U	TK100
Clio	2001	2005	RN30U	TK60/TK100
Clio	2006	2011	PG33U	TK60/TK100
Clio	2012	Today	PG33U	TK60/TK100
Espace	1995	Today	RN30U	TK100
Kangoo	1998	2001	VE20U	TK100
Kangoo	2002	2008	VE20U	TK60/TK100
Kangoo	2009	Today	PG33U	TK60/TK100
Kangoo Express	2010	Today	PG33U	TK60/TK100
Laguna	1996	2001	RN30U	TK100
Laguna	1996	2001	VE20U	TK100
Master	1999	2001	RN30U	TK100
Master	2003	2010	RN30U	TK60/TK100
Master	2011	Today	PG33U	TK60/TK100
Mégane	1996	1998	RN30U	TK100
Mégane	1998	2003	RN30U	TK40/TK100
Mégane	1998	2000	RN30U	TK40/TK100
Modus	2004	2008	PG33U	TK60/TK100
New Clio	2006	Today	PG33U	TK60/TK100
Safrane	1995	Today	RN30U	TK100
Safrane	1995	Today	VE20U	TK100
Scénic	1996	1998	RN30U	TK100
Trafic	2002	Today	RN30U	TK60/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>RENAULT (F)</b> 				
Twingo	1995	2001	VE20U	TK100
Twingo	2002	2007	VE20U	TK60/TK100
Twingo	2007	2011	PG33U	TK60/TK100
Twingo	2012	Today	PG33U	TK60/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>ROVER (GB)</b> 				
400	1997	1998	RV3U	TK100
600	1998	Today	RV3U	TK100
618	1996	Today	RV3U	TK100
620	1996	Today	RV3U	TK100
800	1997	1998	RV3U	TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>SATURN (USA)</b> 				
Astra	2008	2009	B106U	TK60/TK100
Aura	2007	2009	B106U	TK60/TK100
Outlook	2007	2009	B106U	TK60/TK100
Sky	2007	2010	B106U	TK60/TK100
Vue	2008	Today	DAE47U	TK60/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>SCION (USA)</b> 				
TC	2005	2010	TR47U	TK40/TK100
XA	2004	2007	TR47U	TK40/TK100
XB	2004	2008	TR47U	TK40/TK100
XD	2008	Today	TR47U	TK40/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>SEAT (E)</b> 				
Alhambra	1996	1998	V66U	TK100
Alhambra	2000	-	V66U	TK50
Alhambra	2002	2008	V66U	TKM
Altea	2004	Today	V66U	TKM
Altea Freetrack	2007	Today	V66U	TKM
Altea XL	2006	Today	V66U	TKM
Arosa	1997	1999	V66U	TK100
Arosa	2001	2005	V66U	TK50
Cordoba	1995	1998	V35U	TK100
Cordoba	2001	Today	V66U	TKM
Exeo	2008	Today	V66U	TKM
Ibiza	1995	1998	V35U	TK100
Ibiza	2000	Today	V66U	TKM
Inca	1996	1998	V35U	TK100
Inca	2000	2003	V66U	TK50
Leon	1999	Today	V66U	TKM
Marbella	1995	1998	V35U	TK100
Mii	2012	Today	V66U	TKM
Toledo	1995	1998	V35U	TK100
Toledo	1999	2004	V66U	TK100
Toledo	2005	Today	V66U	TKM


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>ŠKODA (CZ)</b> 				
Citigo	2012	Today	V66U	TKM
Fabia	2000	2004	V66U	TKM
Fabia	2005	2010	V66U	TKM
Fabia	2011	Today	V66U	TKM
Felicia	1998	1999	V66U	TK100
Felicia	1999	Today	V66U	TKM
Octavia	1997	2000	V66U	TK100
Octavia	2001	Today	V66U	TKM
Pick-up	1999	Today	V66U	TK100
Roomster	2006	Today	V66U	TKM
Roomster Scout	2007	Today	V66U	TKM
Superb	2002	Today	V66U	TKM
Yeti	2009	Today	V66U	TKM


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>SMART (D)</b> 				
Forfour	2004	2006	MT15U	TK60/TK100
ForTwo	2008	Today	PG33U	TK60/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>STERLING (USA)</b> 				
Bullet	2008	Today	Y160U	TK60/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>SUBARU (J)</b> 				
B9 Tribeca	2005	2007	SUB2U	TK40/TK100
B9 Tribeca	2007	Today	SUB1U	TK40/TK100
Baja	2005	2007	SUB2U	TK40/TK100
Forester	1998	2003	NS34U	TK40/TK100
Forester	2004	2007	SUB2U	TK40/TK100
Forester	2011	Today	SUB1U	TK40/TK100
Forester (Aus)	1998	2004	SUB2U	TK40/TK100
Impreza	1996	2000	NS27U	TK100
Impreza	1998	2003	NS34U	TK40/TK100
Impreza	2004	2007	SUB2U	TK40/TK100
Impreza	2008	Today	SUB1U	TK40/TK100
Impreza (Aus)	1998	2004	SUB2U	TK40/TK100
Justy	1996	2003	SU15U	TK40/TK100





MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>SUBARU (J)</b> 				
Justy	1996	2005	SU15U	TK24/TK100
Justy G3X	2004	Today	SU18U	TK40/TK100
Legacy	1996	1998	NS27U	TK100
Legacy	1998	2004	SUB2U	TK40/TK100
Legacy (EU)	2004	Today	SUB1U	TK40/TK100
Legacy (USA)	2005	Today	SUB2U	TK40/TK100
Liberty (Aus)	1998	2003	SUB2U	TK40/TK100
Outback	1996	1998	NS27U	TK100
Outback	1998	2004	NS34U	TK40/TK100
Outback (Aus)	1998	2003	SUB2U	TK40/TK100
Outback (EU)	2004	Today	SUB1U	TK40/TK100
Outback (USA)	2005	Today	SUB2U	TK40/TK100
Trezia	2011	Today	TR47U	TK40/TK100
WRX	2000	Today	SUB2U	TK40/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>SUZUKI (J)</b> 				
Alto	1996	2002	SU17U	TK24/TK100
Alto	1996	2002	SU15U	TK40/TK100
Alto	1996	2002	SU17U	TK40/TK100
Alto	2002	2007	SU17SU	TK40/TK100
Alto	2008	Today	SU20U	TK60/TK100
Baleno	1997	2001	SU15U	TK24/TK100
Bandit	2006	Today	SU13SU	TK40/TK100
DSXR 600	2006	Today	SU13SU	TK40/TK100
Equator	2009	Today	NS34U	TK60/TK100
Escudo (J)	1996	2002	SU15U	TK24/TK100
Escudo (J)	1996	2002	SU17U	TK40/TK100
Grand Vitara	1996	2002	SU17U	TK40/TK100
Grand Vitara	2002	Today	SU19U	TK60/TK100
Grand Vitara	2010	Today	SU19U	TK60/TK100
GSR	2007	Today	SU13SU	TK40/TK100
GSX	2006	Today	SU13SU	TK40/TK100
Ignis	2000	Today	SU17U	TK40/TK100
Intruder	2007	Today	SU13SU	TK40/TK100
Jimny	1999	2002	SU17U	TK24/TK100
Jimny	2002	Today	SU17U	TK40/TK100
Liana	2001	2005	TR47U	TK40/TK100
Splash	2008	Today	SU19U	TK60/TK100
Swift	1995	2004	SU15U	TK24/TK100
Swift	1995	2004	SU17U	TK40/TK100
Swift	2005	Today	SU19U	TK60/TK100
SX4	2006	Today	SU19U	TK60/TK100
Vitara	1995	2001	SU15U	TK24/TK100
Vitara	1996	2001	SU17U	TK40/TK100
V-Strom	2007	Today	SU13SU	TK40/TK100
Wagon R	1998	2001	SU17U	TK24/TK100
Wagon R	2001	2003	SU18U	TK100
XL7 (USA)	2007	Today	B106U	TK60/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>SUZUKI INDIA (IND)</b> 				
Omni	2006	2009	SU21U	TK40/TK100
Omni	2009	Today	SU21U	TK60/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>TATA (IND)</b> 				
Aria	2010	Today	RV4U	TK60/TK100
Indica Vista	2009	Today	RV4U	TK60/TK100
Indigo Manza	2009	Today	RV4U	TK60/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>TOYOTA (J)</b> 				
4 Runner	1995	2002	TR47U	TK24/TK100
4 Runner	2003	Today	TR47U	TK40/TK100
Alphard	2005	Today	TR47U	TK40/TK100
Aurion (Aus)	2006	Today	TR47U	TK40/TK100
Auris	2006	Today	TR47U	TK40/TK100
Avalon	2005	Today	TR48U	TK40/TK100
Avensis	1998	2000	TR56U	TK24/TK100
Avensis	2000	2003	TR48U	TK40/TK100
Avensis	2003	Today	TR56U	TK40/TK100
Avensis Verso	2001	2003	TR47U	TK24/TK100
Aygo	2005	Today	PG33U	TK40/TK100
Camry	1995	2003	TR47U	TK24/TK100
Camry	1996	2005	TR47U	TK40/TK100
Camry	2003	Today	TR48U	TK40/TK100
Carina	1996	2000	TR56U	TK24/TK100
Carina	1996	2000	TR47U	TK100
Celica	1996	2000	TR47U	TK100
Celica	2000	2005	TR47U	TK24/TK100
Celsior	1998	2004	TR49U	TK24/TK100
Celsior	2000	2004	TR49U	TK40/TK100
Century	1998	Today	TR47U	TK24/TK100
Colorada	1997	Today	TR47U	TK24/TK100
Corolla	1996	1999	TR47U	TK24/TK100
Corolla	2000	2004	TR47U	TK24/TK100
Corolla	2005	Today	TR47U	TK40/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>TOYOTA (J)</b> 				
Echo	1999	2005	TR41U	TK24/TK100
Echo Verso	2002	2005	TR47U	TK40/TK100
FJ Cruiser	2007	Today	TR47U	TK40/TK100
Fortuner	2007	Today	TR47U	TK40/TK100
Gaia	1999	2004	TR47U	TK24/TK100
Hiace	1997	2006	TR47U	TK24/TK100
Hiace	2007	Today	TR47U	TK40/TK100
Hilux	1999	2004	TR47U	TK40/TK100
Hilux	2005	2010	TR47U	TK40/TK100
Hilux	2011	Today	TR47U	TK40/TK100
Innova Kijang	2005	Today	TR47U	TK40/TK100
iQ	2008	Today	TR47U	TK40/TK100
Land Cruiser	1995	2003	TR47U	TK24/TK100
Land Cruiser	1998	2002	TR47U	TK24/TK100
Land Cruiser	2003	Today	TR47U	TK40/TK100
Land Cruiser (EUR)	2003	Today	TR47U	TK40/TK100
Land Cruiser 100	1998	2002	TR47U	TK24/TK100
Land Cruiser 100	2003	2008	TR47U	TK40/TK100
Land Cruiser 120	2002	Today	TR47U	TK40/TK100
Land Cruiser 90	1996	2002	TR47U	TK24/TK100
Land Cruiser Prado	2002	Today	TR47U	TK40/TK100
Matrix	2005	Today	TR47U	TK40/TK100
MR 2	1997	2007	TR41U	TK24/TK100
Picnic	1996	2003	TR47U	TK24/TK100
Picnic	2003	2008	TR47U	TK40/TK100
Prado	1996	Today	TR47U	TK24/TK100
Previa	2000	2008	TR47U	TK40/TK100
Prius	2000	2003	TR47U	TK24/TK100
Prius (EUR)	2007	Today	TR48U	TK40/TK100
Progress	1998	Today	TR48U	TK24/TK100
Rav 4	1996	2004	TR47U	TK24/TK100
Rav 4	2005	Today	TR47U	TK40/TK100
Reiz	2005	Today	TR47U	TK40/TK100
Sequoia	2001	2003	TR47U	TK24/TK100
Sequoia	2003	Today	TR47U	TK40/TK100
Sienna	1999	2003	TR47U	TK24/TK100
Sienna	2004	Today	TR47U	TK40/TK100
Solara	1999	2003	TR47U	TK24/TK100
Solara	2004	Today	TR47U	TK40/TK100
Starlet	1997	1999	TR41U	TK100
T.U.V.	2003	Today	TR47U	TK40/TK100
Tacoma	2004	Today	TR47U	TK40/TK100
Tarago	2003	Today	TR48U	TK40/TK100
Vios	2007	Today	TR47U	TK40/TK100
Wish	2004	Today	TR47U	TK40/TK100
Yaris	1999	2001	TR41U	TK24/TK100
Yaris	2001	2005	TR56U	TK24/TK100
Yaris	2006	2011	TR56U	TK40/TK100
Yaris	2012	Today	TR56U	TK60/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>TOYOTA (USA)</b> 				
4Runner	1999	2002	TR47U	TK24/TK100
4Runner	2003	2010	TR47U	TK40/TK100
Avalon	1998	2004	TR47U	TK24/TK100
Avalon	2005	Today	TR47U	TK40/TK100
Avanza	2004	Today	TR47U	TK40/TK100
Corolla	2005	2010	TR47U	TK40/TK100
FJ Cruiser	2007	2010	TR47U	TK40/TK100
Hiace	2007	Today	TR47U	TK40/TK100
Highlander	2001	2003	TR47U	TK24/TK100
Highlander	2003	Today	TR47U	TK40/TK100
Sequoia	2001	Today	TR47U	TK40/TK100
Sienna	1999	Today	TR47U	TK40/TK100
Solara	2002	Today	TR47U	TK40/TK100
Tacoma	2005	Today	TR47U	TK40/TK100
Tundra	2005	Today	TR47U	TK40/TK100
Yaris	2007	Today	TR47U	TK40/TK100


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>TOYOTA JAPAN</b> 				
Alphard	2003	Today	TR47U	TK40/TK100
Aristo	1998	2005	TR53U	TK24/TK100
bB	2000	2005	TR47U	TK40/TK100
Brevis	2001	Today	TR53U	TK40/TK100
Caldina	2002	2004	TR47U	TK40/TK100
Celsior	1998	2004	TR53U	TK24/TK100
Corolla Fielder	2004	Today	TR47U	TK40/TK100
Corolla Runix	2004	Today	TR47U	TK40/TK100
Corolla Spacio	2003	Today	TR47U	TK40/TK100
Crown	1999	2005	TR53U	TK40/TK100
Dyna	2008	Today	TR47U	TK40/TK100
Estima	2003	Today	TR47U	TK40/TK100
Fun Cargo	2003	2005	TR47U	TK40/TK100
Hiace	1995	Today	TR47U	TK40/TK100
Hilux	1999	2004	TR47U	TK24/TK100

# HORSESHOE GUIDE | GUIDA HORSESHOE


MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>TOYOTA JAPAN</b> 				
Hilux	2005	Today	TR47U	TK40/TK100
Ipsium	1996	Today	TR47U	TK40/TK100
Isis	2003	Today	TR47U	TK40/TK100
Ist	2003	Today	TR47U	TK40/TK100
Kluger	2001	Today	TR47U	TK40/TK100
Land Cruiser Prado	2000	2002	TR47U	TK24/TK100
Land Cruiser Prado	2000	2002	TR53U	TK24/TK100
Land Cruiser Prado	2002	Today	TR47U	TK40/TK100
Mark 2	2000	2006	TR47U	TK40/TK100
Mark X	2004	Today	TR47U	TK40/TK100
Noah	2004	Today	TR47U	TK40/TK100
Open Deck	2000	2005	TR47U	TK40/TK100
Origin	2000	Today	TR53U	TK40/TK100
Platz	1999	2002	TR41U	TK24/TK100
Platz	2003	2005	TR47U	TK40/TK100
Progres NC300	1998	2006	TR53U	TK24/TK100
Pronard	2000	2002	TR47U	TK24/TK100
Raum	2003	Today	TR47U	TK40/TK100
Rav 4	2003	Today	TR47U	TK40/TK100
Regiusace	2007	Today	TR47U	TK40/TK100
Sienta	2003	Today	TR47U	TK40/TK100
Some models	1996	Today	TR51U	TK40/TK100
Toyoace	2008	Today	TR47U	TK40/TK100
Vanguard	2005	Today	TR47U	TK40/TK100
Verossa	2001	2004	TR47U	TK24/TK100
Vitz	2003	Today	TR47U	TK40/TK100
Voxy	2004	Today	TR47U	TK40/TK100
Windom	2001	2004	TR53U	TK24/TK100
Wish	2003	Today	TR47U	TK40/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>TRIUMPH (GB)</b> 				
Speed Triple	2011	Today	ZAD20U	TK60/TK100
Tiger	2011	Today	ZAD20U	TK60/TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>VOLKSWAGEN (D)</b> 				
Amarok	2010	Today	V66U	TKM
Beetle	1998	Today	V66U	TKM
Bora	1998	2005	V66U	TKM
Cabrio	2000	2005	V66U	TK50
Caddy	1995	1998	V35U	TK100
Caddy	2000	2003	V35U	TK50
Caddy	2004	Today	V35SU	TKM
Caravelle	2004	2009	V66U	TKM
Crafter	2006	Today	V66U	TKM
Cross Golf	2006	Today	V66U	TKM
Dasher	1997	1997	V66U	TK100
Dasher	1998	Today	V66U	TKM
Eos	2006	Today	V66U	TKM
Euro Van	2000	2004	V66U	TKM
Fox	2005	Today	V66U	TKM
Gol	1999	Today	V70U	TKM
Gol	2009	Today	V66U	TKM
Golf	1995	1997	V35U	TK100
Golf	1998	Today	V66U	TKM
Golf Cabrio	2000	2004	V66U	TK50
Golf Cabrio	2004	Today	V66U	TKM
Individual	2004	Today	V66U	TKM
Jetta	2000	Today	V66U	TKM
Kombi	2003	2009	V66U	TKM
Lupo	2000	2005	V66U	TK50
Magotan	2007	Today	V66U	TKM
Multivan	2003	Today	V66U	TKM
Multivan	2004	2009	V66U	TKM
New Beetle	1998	Today	V66U	TKM
Parati	1997	1999	V66U	TK100
Parati	1999	Today	V70U	TKM
Passat	1995	1996	V35U	TK100
Passat	1997	1998	V66U	TK100
Passat	1998	2005	V66U	TKM
Passat	2006	Today	V66U	TKM
Phaeton	2003	Today	V66U	TK60/TK100
Polo	1995	1998	V35U	TK100
Polo	2000	2001	V66U	TK50
Polo	2001	Today	V66U	TKM
Polo	2006	Today	V66U	TK60/TK100
Quantum	1997	1998	V66U	TK100
Quantum	1999	Today	V66U	TKM
Rabbit	1997	1998	V66U	TK100
Rabbit	1999	Today	V66U	TKM
Routan	2008	Today	Y170U	TK60/TK100
Santana 2000	1998	Today	V66U	TKM
Saveiro	1999	Today	V35SU	TKM
Scirocco	2008	Today	V66U	TKM
Sharan	1995	1998	V66U	TK100

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>VOLKSWAGEN (D)</b> 				
Sharan	2000	Today	V66U	TK50
Sharan	2001	2006	V66U	TKM
Spacefox	2005	2008	V66U	TKM
Tiguan	2007	Today	V66U	TKM
Touareg	2008	Today	V66U	TK60/TK100
Touran	2003	Today	V66U	TKM
Touran (USA)	2007	Today	V66U	TK60/TK100
Transporter	1995	1998	V35U	TK100
Transporter	2001	2004	V35U	TK50
Transporter	2004	Today	V66U	TKM
UP!	2012	Today	V66U	TKM
Vento	1995	Today	V35U	TK50
Voyage	2009	Today	V66U	TKM

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>VOLVO (S)</b> 				
S60	2000	Today	VL17U	TKM
V70	2000	2007	VL17U	TKM
XC 70	2003	Today	VL17U	TKM
XC 90	2003	Today	VL17U	TKM

MAKE - MODEL	FROM	TO	HORSESHOE	HEAD
<b>YAMAHA (J)</b> 				
BT1100 Bulldog	2005	Today	YM35U	TK40/TK100
Fazer 8	2010	Today	YM35U	TK40/TK100
FJR1300	2005	Today	YM35U	TK40/TK100
FZ1	2006	Today	YM35U	TK40/TK100
FZ1 Fazer	2006	Today	YM35U	TK40/TK100
FZ6	2004	Today	YM35U	TK40/TK100
FZ8	2010	Today	YM35U	TK40/TK100
FZS1000 Fazer	2005	Today	YM35U	TK40/TK100
Majesty 400	2004	Today	YM35U	TK40/TK100
MT-01 / MT-03	2004	Today	YM35U	TK40/TK100
Some models	2000	Today	YM35SU	TK40/TK100
TDM600	2005	Today	YM35U	TK40/TK100
TDM900	2010	Today	YM35U	TK40/TK100
T-Max	2005	Today	YM35U	TK40/TK100
VMAX	2009	Today	YM35U	TK40/TK100
X-City 125	2007	Today	YM35U	TK40/TK100
XJ6 Diversion	2009	Today	YM35U	TK40/TK100
XJR 1300	2004	Today	YM35U	TK40/TK100
X-Max 125	2006	Today	YM35U	TK40/TK100
X-Max 250	2006	Today	YM35U	TK40/TK100
XT 600 Ténéré	2008	Today	YM35U	TK40/TK100
XT1200Z Super Ténéré	2010	Today	YM35U	TK40/TK100
XT660	2004	Today	YM35U	TK40/TK100
XT660Z Ténéré	2007	Today	YM35U	TK40/TK100
XTR	2004	Today	YM35U	TK40/TK100
XTX	2004	Today	YM35U	TK40/TK100
XV1900A	2009	Today	YM35U	TK40/TK100
XVS 1100 DragStar	2003	Today	YM35U	TK40/TK100
XVS 650 DragStar	2004	Today	YM35U	TK40/TK100
XVS950A	2009	Today	YM35U	TK40/TK100
YZF-R1	2005	Today	YM35U	TK40/TK100
YZF-R6	2003	Today	YM35U	TK40/TK100